

Type of service	Interim	Full
<b>Interior</b>		
Check seat belt condition and operation		√
Reset service light	√	√
Check correct operation of dashboard instruments and warning lights	√	√
Run diagnostic test if required	√	√
Stamp service record	√	√
Check correct operation of air conditioning		√
Replace the cabin filter		*
Check correct operation of windscreen washers	√	√
Check correct operation of windscreen wipers replace if necessary	√*	√*
Check horn	√	√
Check correct operation of clutch including vibration and noises		√
<b>Exterior</b>		
Check correct operation of all exterior lights replace any bulbs as necessary	√	√
Check headlamps for clarity advise polishing if opaque		√
Check bodyshell and chassis for excessive corrosion	√	√
Check windscreen for cracks and stone chip damage	√	√
Check mirrors	√	√
<b>Wheels and Tyres</b>		
Check and adjust tyre pressures	√	√
Check security of wheel nuts	√	√
Check wheel bearings for noise and play		√
Check for side wall damage	√	√
Check alloy wheels for pot hole damage, distortion and cracking		√
Check for adverse tyre wear	√	√
Check and adjust front wheel tracking if required		*
Check for deformities and cracking	√	√
Check spare wheel tyre condition and pressure		√
<b>Brakes</b>		
Check for brake pad and brake disc wear	√	√
Check and adjust brake fluid level	√	√
Check condition of brake fluid		√
Flush through and replace brake fluid		*
Check condition of all flexible brake pipes for damage, routing & perishing		√
Check condition of rigid brake pipes for damage or corrosion		√
Check correct operation of handbrake		√
Check handbrake for excessive travel and adjust if necessary		√
Check for binding brakes at each wheel	√	√
<b>Suspension and steering</b>		
Check for play in steering rack at steering wheel		√
Check for wear in track rod ends and condition of rubber gaiters	√	√
Check for wear in inner steering arm joints and condition of rubber bellows	√	√
Check power steering fluid level and condition top up if required	√	√
Check power steering pipes and joints for leaks		√
Check for wear in anti roll bar rubber mounts and drop links	√	√
Check for deterioration of rubber bushes in front and rear suspension	√	√
Check for leaks and correct operation of shock absorbers front and rear		√
Check suspension springs for condition and breakages	√	√
<b>Engine and drivetrain</b>		
Check engine for correct running, smoothness, responsiveness and noises		√
Change engine oil and oil filter	√	√
Check condition of auxiliary belt and replace if necessary	√*	√*
Replace cam belt, follower and tensioner		*

Check condition of driveshafts, CV joints and gaiters	√	√
Replace air filter		√
Replace fuel filter (Diesel cars)		√
Replace spark plugs (Petrol cars)		√
Top up washer bottle	√	√
Check level, strength and condition of anti freeze in coolant reservoir	√	√
Lubricate the bonnet release mechanism	√	√
Check for engine and transmission oil and coolant leaks	√	√
Check condition of all rubber coolant hoses for damage and deterioration		√
Check exhaust system for condition and leaks	√	√
Check condition of turbo charger boost hoses for security, splits and leaks		√
Check radiator, intercooler and condenser for signs of damage or leaks		√
Check exhaust system rubber hangers replace if necessary		√*
Check operation of battery test if necessary		√
Thorough inspection of engine and drivetrain for potential issues		√

\* Additional cost items as required